

Three Position Selector Switches, Non-Illuminated (Complete Kits) ①

Switching Positions	Contact Block(s) ⊗⊗	Plastic operator with plastic bezel		Metal operator with metal bezel	
		Catalog Number	Price	Catalog Number	Price
 M3	Oper. Only	D7P-♣M32	18.72	D7M-♣M32	20.75
	2	D7P-♣M32P▼	51.77	D7M-♣M32P▼	53.73
	3	D7P-♣M32P▼	65.31	D7M-♣M32P▼	67.33
 L3	Oper. Only	D7P-♣L32	18.72	D7M-♣L32	20.75
	2	D7P-♣L32P▼	51.77	D7M-♣L32P▼	53.73
	3	D7P-♣L32P▼	65.31	D7M-♣L32P▼	67.33
 R3	Oper. Only	D7P-♣R32	18.72	D7M-♣R32	20.75
	2	D7P-♣R32P▼	51.77	D7M-♣R32P▼	53.73
	3	D7P-♣R32P▼	65.31	D7M-♣R32P▼	67.33
 B3	Oper. Only	D7P-♣B32	18.72	D7M-♣B32	20.75
	2	D7P-♣B32P▼	51.77	D7M-♣B32P▼	53.73
	3	D7P-♣B32P▼	65.31	D7M-♣B32P▼	67.33


Complete Kit Ordering Instructions

D7P	♣	M3	2	P	▼
Oper. Construction D7P - Plastic operator with plastic bezel (Type 4/4X/13, IP66) D7M - Metal operator with metal bezel (Type 4/13, IP66)	Operator Type S - Standard knob H - Long knob ④ (add \$8.20)	Oper. Function M3 - Maintained, 60° switching angle L3 - Spring return from left, 60° R3 - Spring return from right, 60° B3 - Spring return from left and right, 60°	Knob Color 2 - Black knob, white insert	Mounting Latch P - Plastic latch (D7P and D7M offered with plastic latch as standard) M - Metal latch Note: For metal latch add \$1.69	Contacts ⊗⊗ X10 - 1NO X01 - 1NC → X20 - 2NO X02 - 2NC X11 - 1NO/1NC X30 - 3NO X03 - 3NC X21 - 2NO/1NC X12 - 1NO/2NC <i>Add \$13.55 for each additional standard contact block</i>

→ Positive Opening per EN60947-5-1 (applies to all NC contact block styles)

Contact Development Table

Contact Type	Mounting Position on Latch			
NO	Left (slot 1)	X	0	0
NO	Center (slot 3)	X	0	X
NO	Right (slot 2)	0	0	X
NC	Left (slot 1)	0	X	X
NC	Center (slot 3)	0	X	0
NC	Right (slot 2)	X	X	0
Special Center Activation ⑤				
NO	Center CL	X	0	0
NO	Center CR	0	0	X
NC	Center CL	0	X	X
NC	Center CR	X	X	0



Switching Angle

① Legend plates sold separately. See page H73 for information.

② Up to 6 contact blocks (3 across / 2 high) can be attached.

③ See page H74 for complete kit ordering information on other special contact blocks: Early make, late break, low voltage, and screwless contact blocks.

④ 30mm hole spacing will not work if long knob lever is used. See page H86 for recommended operator panel spacing.

⑤ Standard operators not available for Center position activation (CL/CR).

Modification can be field installed with accessory item D7-ACP for center position activation. See Accessory page H67 to order.